# AMBIENT AIR MONITORING DATA: APPROACHES, CONSIDERATIONS, LIMITATIONS, AND EVALUATION

Presented by:

David Brymer

&

Laurel Carlisle

**Texas Natural Resource Conservation Commission** 

### **Ambient Air Monitoring Techniques**

#### Non-Criteria Pollutants

- Volatile Organics
  - On-site determinations
    - TNMHC, FTIR, UV-DOAS, auto GC, portable GC
  - Field Collection with Lab Analysis
    - Canisters
    - Tedlar Bags
    - Solid Sorbents (multibed)
    - Reactive sorbents
      - DNPH for carbonyls
      - HBr tubes for ethylene/propylene oxides

### **Semi-Volatile Organics**

- On-Site Determinations
  - Very limited
- Field Collection with Lab Analysis
  - Filter/PUF plugs for PAHs, dioxins/furans,
     PCBs, some pesticides
  - Solid sorbents

### **Particulate Matter**

- PM<sub>10</sub> or PM<sub>2.5</sub> gravimetric
- Metals
- Cations/anions and other speciated data

### **Data Uncertainty**

- Data Quality Objectives vs. Reality
- Sampler Site Selection
  - What do the data represent?
- Unmeasured bias
  - Conversion efficiency, sampler recovery, sample media storage effects, breakthrough at elevated temperatures
- Interferences
  - Ozone, pH, inter-elemental interferences, water, CO<sub>2</sub>
- Time-integrated samples
  - Is the 1-hour sample really representative of the entire hour?
- Concentration level of quality control checks
- Method detection limits
  - How realistic are they?

### **Data Validation**

Why does it take so long when the analysis only takes an hour?

- Sample media quality control
- Sampling quality control
- Analytical quality control
- Electronic data review
- Final review procedure

### Sample Media Quality Control

- Blanks
- Recovery checks

### **Sampling Quality Control**

- Sampler recovery
- Duplicates/blanks
- Matrix spikes
- Flow rates/dates and times
- Sample integrity/custody checks

### **Analytical Quality Control**

- Calibration, second source standard checks
- Tune checks
- System blanks, calibration verification, duplicates
- Internal standards/surrogates
- Review of peak identifications and integrations


### **Electronic Data Review**

Accuracy check


### **Final Review Procedure**

- Identify anomalies
- Review all quality control data for sources of error
- Review any confirmatory data
- Review potential sources, wind direction, precipitation, operator notes
  - Gasoline, insecticide spraying, solvent use in monitoring station
- Identify needs for additional monitoring to define source OR confirm proper operation of instrumentation


#### TNRCC Community Air Toxics Monitoring Network, 2000




TNRCC Ambient Air Monitoring Network for Cardonyis, 2000




### Annual Average Arsenic Levels in Texas 2000



#### El Paso Annual Arsenic Data




### Annual Average Benzene Levels in Texas TNRCC Community Air Toxics Monitoring Network




**Monitoring Site** 

### Annual Average 1,3-Butadiene Levels in Texas TNRCC Community Air Toxics Monitoring Network



**Monitoring Site** 

### Annual Average Formaldehyde Levels in Texas 2000



**Monitoring Site** 

## What are Effects Screening Levels?

- Effects Screening Levels (ESLs) are compound-specific guideline air concentrations.
- ESLs are set at levels below which those reported in the scientific literature to result in an adverse health or welfare effect.

## What are Effects Screening Levels?

- ESLs are set to protect sensitive members of the population:
  - The elderly
  - Children
  - The sick
  - Pregnant women

## Deriving Effects Screening Levels

- Spectrum of effects considered:
  - Human Health Effects
    - Acute
    - Chronic
    - Nuisance
  - Effects on vegetation
  - Effects on material

## Deriving Effects Screening Levels


- Constituents tend to induce a spectrum of possible effects
- For example,
  - Low levels-odors
  - Intermediate levels-irritation
  - High levels-organ damage

An ESL is set to protect against the effect occurring at the lowest concentration.

### Case Study

- •Network monitoring shows elevated benzene
- •ESL review
- •Mobile monitoring helps identify sources
- •Facility specific fixed monitoring to aid in process management

Number of Days Elevated 1,3-Butadiene Fence-line Levels Reported 11/17/98 - 4/30/99



1,3-Butadiene Instantaneous Concentration (parts per billion by volume)



### What We Have Learned

- Uncertainties associated with both modeling and monitoring
- Both needed to evaluate exposure
- Competing demands for limited monitoring resources
- Identify legal authority to correct problems once identified